

# ASSEMBLY INSTRUCTIONS FOR SAMPLE KNOCK DOWN **ECORRCRATE** ECO FRIENDLY CORRUGATED CRATE



**STEP 1**—Unpack the Ecorrcrate. When you take off the lid you will find two End Walls with Flaps and two Side Walls.



**STEP 2**—Insert End Walls with Flaps into base of Ecorrcrate as shown.



**STEP 3**—Insert Side Walls by sliding them securely into the Wing Wall to form a tight fit.



**STEP 4**—Put the top back on the crate and strap. When requested we also put a special double sided tape on the inside of the flaps.

The Sample Crate comes in our Knock Down form with a telescoping top. The advantage is that it is extremely compact when in the knock down state. This allows for easy storage and saves on space. The disadvantage is that the top does not fit tight when assembled. Once strapped it is secure, but some clients prefer a tight top. I have pictures below of both styles while in the knock down and set up configurations.



Knock Down Tight Top

Knock Down Telescoping



Setup Tight Top

Setup Telescoping



An Ecorrcrate comes standard on a wood base, but can also be ordered with a corrugated base, or no base at all similar to the sample Ecorrcrate. The Ecorrcrate is custom made to customers specific needs.

