

SHURSEAL® AUTOMATED PACKAGING SOLUTIONS

FELT PAD REPLACEMENT GUIDE

TOOLS NEEDED:

- J-B WELD® MinuteWeld™ Epoxy
- Small flathead screwdriver or comparable tool for mixing epoxy
- Razor or box cutter
- Alcohol
- Rag



STEP 1

Use razor blade or box cutter to remove debris from knife guard left by previous oil pad.



STEP 2

Use alcohol and rag to wipe any oil from the knife guard. This allows the epoxy to bond securely.



STEP 3

Cut the ends off the epoxy tubes and eject a small amount of epoxy from both tubes into a small, durable container or other surface. Mix well and apply to one side of the felt pad. For quickest results, use a 1-minute epoxy; however, a 5-15 minute epoxy can also be used.



STEP 4

When applying, the felt should be flush with the top and inside edge of the knife guard.



STEP 5

Allow ample time to dry before applying oil to felt pad. Drying time is dependent on type of epoxy used, so follow manufacturer's recommendations.