Flap folding presentation to the LD-16AE.

Prior to placing boxes on the conveyor, flaps must be in the correct orientation.



Inner flaps must be slightly angled and "sandwiched" between the outer flaps



Outer flaps should remain in the upright position to prevent jams



Outer flaps = long side Inner flaps = short side