

2EZSB ADJUSTABLE CARRIAGE FOR CASE LENGHT INDICATORS SETUP GUIDE

STEP #1 = E-STOP MACHINE

CASE ID#		1504174-0001					
CARRIAGE RETRACT ADJUST	A	Case Length	11.50				
MAGAZINE HEIGHT	B	Case Width	10.00				
MAGAZINE SIDE RAIL (sq.arm side)	C	Knock Down Length	21.18				
UPPER CASE OPENING DEVICE	D	Adjust to top of case with the spring located on the minor panel 1" from DIE CUT					
VACUUM CUPS	E	Position adjustable cups as needed					
MAJOR FLAP OPENER (If Applicable)	F	Adjust so that the device just breaks the "Major Flap"					
HOLD DOWN PLATE	G	Case Ht. with bottom folded	9.75				
PLOW / BELT DRIVES	H	Case Width	10.00				